

Supplemental Asbestos/Suspect Asbestos Information for Planning Work

When performing work that involves asbestos containing material hold points or equivalent (e.g. pre/post checklist) must be utilized in the work plan to mitigate the hazards (e.g. prior to downgrading a regulated area).

When performing work that involves asbestos containing material a competent person must be involved in work plan development and approve the final work plan.

Any Class I, II or III work involving asbestos containing material must go through High Hazard Review Board (HHRB) prior to work start. With appropriate approval Class IV and 29 CFR 1910.1001 (F)(3), *Specific Compliance and Work Practices for Brake and Cutch Repair* may be excluded.

Prior to any activity which involves the potential disturbance of any suspect material, an Asbestos Hazard Evaluation Specialist (AHES) must be notified for determination of ACM present and a walkdown must be conducted including at a minimum Occupational Safety Representative, a competent asbestos person and AHES.

The following is a list of suspect materials and does not include every product/material that may contain asbestos. Only wood, metal, rubber, foam and glass are considered not to be suspect materials.

Cement Pipes	Elevator Brake Shoes
Cement Wallboard	HVAC Duct Insulation
Cement Siding (Transite)	Boiler Insulation
Asphalt Floor Tile	Breaching Insulation
Vinyl Floor Tile	Ductwork Flexible Fabric Connections
Vinyl Sheet Flooring	Cooling Towers
Flooring Backing	Pipe Insulation (corrugated air-cell, block, etc.)
Construction Mastics (floor tile, carpet, ceiling tile, etc.)	Heating and Electrical Ducts
Acoustical Plaster	Electrical Panel Partitions
Decorative Plaster	Electrical Cloth
Textured Paints/Coatings	Electric Wiring Insulation
Ceiling Tiles and Lay-in Panels	Gaskets
Spray-Applied Insulation	Roofing Shingles

Blown-in Insulation	Roofing Felt
Fireproofing Materials	Base Flashing
Taping Compounds (thermal)	Thermal Paper Products
Packing Materials (for wall/floor penetrations)	Fire Doors
High Temperature Gaskets	Caulking/Putties
Laboratory Hoods/Table Tops	Adhesives
Laboratory Gloves	Wallboard
Fire Blankets	Joint Compounds
Fire Curtains	Vinyl Wall Coverings
Elevator Equipment Panels	Spackling Compounds

The following list of suspect material is a sample list of the most common types of material encountered;

- Drywall/Joint Compound
- Plasters (acoustical)
- Spray on Fireproofing
- Flooring Materials and associated Mastics (Tiles, Linoleum, Vinyl Flooring)
- Ceiling Tiles
- Pipe Insulation
- Pipe Coatings
- Vermiculite
- Roofing Material
- Gaskets
- Transite
- Caulking
- Window Glazing